

## CREDIT SALE

- Press 1
- Choose **CREDIT**
  - Select the desired card type
- Enter sale amount and press **ENTER**
  - Enter surcharge amount and press **ENTER**
- Swipe or insert customer card
  - Select the desired language
  - Have customer enter PIN on PIN pad and press **ENTER**
- Terminal dials out, and receipt prints
  - Remove the card

## MAIL/PHONE SALE

- Press 1
- Choose **CREDIT**
  - Select the desired card type
- Enter sale amount and press **ENTER**
  - Enter surcharge amount and press **ENTER**
- Enter card number and press **ENTER**
- Enter expiration date (MMYY) and press **ENTER**
- Card present? Choose **YES** or **NO**
  - Enter V-Code/CID Code and press **ENTER**, or press **ENTER** to bypass
  - If bypassed, Choose V-Code option: 1 (Unreadable), 2 (Not Present), 3 (Not Provided)
  - Enter street address number and press **ENTER**, or press **ENTER** to bypass
- Enter Zip Code and press **ENTER**, or press **ENTER** to bypass
- Terminal dials out, and receipt prints

## DEBIT SALE

- Press 1
- Choose **DEBIT**
- Enter sale amount and press **ENTER**
- Enter tip amount and press **ENTER**
- Swipe or insert customer card
  - Select the desired language
  - Enter cash back amount and press **ENTER**, or press **ENTER** to bypass
- Press **ENTER** to accept total
- Have customer enter PIN on PIN pad and press **ENTER**
- Terminal dials out, and receipt prints
  - Remove the card

## CREDIT REFUND

- Press 2
- Choose **CREDIT**
- Enter refund amount and press **ENTER**
- Swipe customer card, insert customer card, or enter card number and press **ENTER**
  - Enter expiration date (MMYY) and press **ENTER**
  - Select the desired language
- Terminal displays Captured, and receipt prints
  - Remove the card

## DEBIT REFUND

- Press 2
- Choose **DEBIT**
- Enter refund amount and press **ENTER**
- Enter original transaction date (MMDDYY) and press **ENTER**
- Enter original transaction time (HHMMSS) and press **ENTER**
- Swipe or insert customer card
  - Select the desired language
- Have customer enter PIN on PIN pad and press **ENTER**
- Terminal dials out, and receipt prints
  - Remove the card

## REVERSAL

- Press 3
- Choose a search option
- Enter retrieval information and press **ENTER**
- Choose **SELECT**
- Press **ENTER** to accept transaction
- Terminal dials out, and receipt prints

## TERMINAL MESSAGES

- AMOUNT DUE/BALANCE DUE:** A partial authorization has occurred. Ask customer for another form of payment for the remaining balance of the sale. Press **ENTER** to print the receipt. Pressing **CANCEL** will not void the transaction.
- AVS (ADDRESS VERIFICATION SERVICE):** Checks if the street address and ZIP code entered match the customer's billing address.
- CALL:** Call Voice Authorization Center. If approved, proceed with Offline Entry.
- HOLD/CALL OR PICK UP CARD:** Hold the card. Use Code 10 procedure. Call the Voice Authorization Center.
- CARD SWIPE ERROR:** Magnetic stripe did not read. Swipe card again or manually key-in account number.
- COMM ERROR:** A communication error has occurred. Check line connections, call Help Desk.

- GB (NUMBER):** Good batch. Batch transmission accepted.
- MANUAL ENTRY NOT ALLOWED:** Current transaction will not allow manual entry. Debit cards may not be manually keyed-in.
- QD (NUMBER) OR RB (NUMBER):** Quit Duplicating or Rejected Batch. Call Help Desk.
- RECORD NOT FOUND:** Invoice number is not found in terminal batch.
- SETTLE FAILED, RETRY:** Settlement failed, call Help Desk.
- V-CODE:** Verification Code. A 3-4 digit non-embossed number found on card signature panel or near embossed account number on front. V-code may be prompted for on a manually-entered transaction.



### QUICK REFERENCE

Bank Name \_\_\_\_\_  
Bank Phone \_\_\_\_\_  
Help Desk Phone \_\_\_\_\_  
V Number \_\_\_\_\_  
Voice Authorization Phone \_\_\_\_\_  
Merchant Number ID \_\_\_\_\_  
Other \_\_\_\_\_  
\_\_\_\_\_

## Quick Reference Guide



## CREDIT OFFLINE ENTRY

- Press 4
- Choose CREDIT
  - *Select the desired card type*
- Enter amount and press ENTER
  - *Enter surcharge amount and press ENTER*
- Swipe customer card, insert customer card, or enter card number and press ENTER
  - *Enter expiration date (MMYY) and press ENTER*
  - *Card present? Choose YES or NO*
  - *Select the desired language*
- Enter approval code (six digits), and press ENTER
- Enter transaction ID (15 digits), and press ENTER
- Terminal displays Captured and receipt prints
  - *Remove the card*

## DEBIT RE-ENTER

- Press 4
- Choose REENTER
- Choose DEBIT
- Choose transaction type
- Swipe customer card, insert customer card, or enter card number and press ENTER
  - *Select the desired language*
- Enter original transaction date (MMDDYY) and press ENTER
- Enter original transaction time (HHMMSS) and press ENTER
- Enter reference retrieval number (12 digits), and press ENTER
- Enter trance number (six digits), and press ENTER
- Enter Network ID (one character), and press ENTER
- Enter settlement date (MMDD), and press ENTER
- Enter approval code (six digits), and press ENTER
- Enter amount and press ENTER
- Enter tip amount and press ENTER
  - *Enter cash back amount and press ENTER, or press ENTER to bypass*
- Press ENTER to accept amount
- Terminal displays Captured, and receipt prints
- Press CANCEL

## AUTHORIZATION ONLY

- Press 8
- Choose AUTH ONLY
- Choose AMT AUTH
- Swipe customer card, insert customer card, or enter card number and press ENTER
  - *Enter expiration date (MMYY) and press ENTER*
  - *Card present? Choose YES or NO*
  - *Enter Zip Code and press ENTER, or press ENTER to bypass*
  - *Select the desired language*
  - *Have customer enter PIN on PIN pad and press ENTER*
- Terminal dials out, and receipt prints
  - *Remove the card*

## BALANCE INQUIRY

- Press 6
- Choose card type
- Swipe customer card, insert customer card, or enter card number and press ENTER
  - *Enter expiration date (MMYY) and press ENTER*
  - *Select the desired language*
  - *Have customer enter PIN on PIN pad and press ENTER*
- Terminal dials out, and receipt prints
  - *Remove the card*

## BENEFITS

- Swipe customer card
- Choose EBT
- Choose transaction type
- Enter sale amount and press ENTER
  - *If Cash Benefits, enter cash back amount and press ENTER*
- Have customer enter PIN on PIN pad and press ENTER
- Terminal dials out, and receipt prints

## VOUCHER

- Press 4
- Choose REENTER
- Choose EBT
- Choose Voucher
- Enter card number and press ENTER
- Enter original transaction date (MMDDYY) and press ENTER
- Enter original transaction time (HHMMSS) and press ENTER
- Enter reference retrieval number (12 digits), and press ENTER
- Enter trance number (six digits), and press ENTER
- Enter Network ID (one character), and press ENTER
- Enter voucher number (15 digits), and press ENTER
- Enter approval code (six digits), and press ENTER
- Enter sale amount and press ENTER
- Terminal displays Captured, and receipt prints
- Press CANCEL

## EBT REFUND

- Press 2
- Choose EBT
- Press ENTER
- Enter refund amount and press ENTER
- Swipe customer card or enter card number and press ENTER
- Press ENTER to accept amount
- Have customer enter PIN on PIN pad and press ENTER
- Terminal dials out, and receipt prints

## ADD CLERK

- Press #
- Choose CLERK MENU
- Choose ADD ID
- Enter clerk ID and press ENTER
- Add Another? Choose YES or NO
  - *If Yes, repeat steps to add another server*

## TRANSACTION ADJUST

NOTE: Adjustments are not allowed on Smart Card/Chip Card sales.

- Press 8
- Choose TRANS ADJUST
- Choose a search option
- Enter retrieval information and press ENTER
- Choose SELECT
- Enter new sale amount and press ENTER
- Terminal displays Captured, and receipt prints

## REPRINT A RECEIPT

- Press 8
- Choose REPRINT
- Choose a search option
- Enter retrieval information and press ENTER
- Choose SELECT
- Choose a receipt type
- Receipt prints

## TIP ADJUST

NOTE: Adjustments are not allowed on Smart Card/Chip Card sales. Tip must be added at time of sale.

- Press 5
- Choose a search option
- Enter retrieval information and press ENTER
- Choose SELECT
- Enter new tip amount and press ENTER
- Terminal displays Captured, and receipt prints
- Add Another? Choose YES or NO
  - *If Yes, repeat steps to add another tip*

## REPORTS

- Press #
- Choose REPORTS MENU
- Choose report: Summary (total amount) or Detail (each transaction)
- Choose PRINT
- Report prints
- Press CANCEL

## VIEW TOTALS

- Press #
- Choose BATCH MENU
- Choose BATCH TOTALS
- Terminal displays totals
- Press ENTER
- Press CANCEL

## MANUAL BATCH SETTLEMENT

- Press 7
- Choose YES
  - *Print Reports? Choose YES or NO*
  - *Report prints*

## FAILED SETTLEMENT

- Terminal will display QDXXXXX or RBXXXXX
- DO NOT DELETE BATCH OR CONTINUE WITHOUT HELP DESK VERIFICATION
- Call Help Desk

## AUTHENTICATE THE TERMINAL

- Press #
- Choose MAINTENANCE
- Choose AUTHENTICATE
- Enter authentication code and press ENTER
- Enter zip code and press ENTER
- Terminal dials out, and receipt prints

## DEACTIVATE THE TERMINAL

- Press #
- Choose MAINTENANCE
- Choose DEACTIVATE
- Choose YES
- Terminal dials out, and receipt prints

## ALPHA CHARACTERS

- Press key corresponding with desired letter
- Press F key until desired letter appears [Number + F key = Letter]

## CARD TYPES ACCEPTED

- Visa
- MasterCard
- American Express
- Discover
- JCB
- Diners Club
- Carte Blanche
- PayPal
- ATM/Debit Cards

## EBT DEFINITIONS

**ELECTRONIC VOUCHER:** Form which is completed by a merchant when a Food Stamp transaction authorization cannot be received through the terminal.

**FCSID (FOOD AND CONSUMER SERVICES IDENTIFIER):** Identifies a merchant as approved to accept Food Stamps.

**VOUCHER AP (VOUCHER APPROVAL CODE):** A Voice Authorized Approval Code received when a Food Stamp transaction authorization through the terminal is not possible. To obtain, call the Voice Authorization Center.

**VOUCHER S/N (VOUCHER SERIAL NUMBER):** A pre-printed number found on an Electronic Voucher form.

NOTE: Italicized steps are optional and may not be prompted for.

NOTE: Printing the customer copy is an option on all transactions.